


Lift bottom connections (Magnet side)

(direction VELO) 



Inner layer (v) TTb

F144 (K) M8A5 F107 (M) M8A4 F108 (L) M8A2 TT104	F141 (K) M10A2 F142 (M) M10A0 F143 (L) M10A1 TT112/FM104	F111 (M) M7B3 F112 (L) M7B5 TT79/FM23	F109 (M) M10B3 F110(L) M10B5 TT152/FM40	F88 (M) M10B3 F87 (L) M10B5 TT63/FM31	F91 (M) M10B3 F92 (L) M10B5 TT64/FM24	F89 (M) M12B1 F90 (L) M12B3 TT46/FM3	F95 (M) M12B1 F96 (L) M12B3 TT88/FM30	F93 (M) M12B1 F94 (L) M12B3 TT16/FM1
F134 (K) M8B3 F135 (M) M8B5 F136 (L) M8B4 TT133	F131 (K) M10B4 F132 (M) M10B2 F133 (L) M10B0 TT36/FM101	F139 (M) M10B1 F140 (L) M10A4 TT80/FM42	F137 (M) M12B0 F138 (L) M12B2 TT25/FM10	F115 (M) M12B0 F116 (L) M12B2 TT67/FM33	F113 (M) M12B0 F114 (L) M12B2 TT23/FM46	F119 (M) M12B4 F120 (L) M12B5 TT53/FM7	F117 (M) M12B4 F118 (L) M12B5 TT34/FM41	F85 (M) M12B4 F86 (L) M12B5 TT17/FM19

Outer layer (x2)

(direction Magnet) 